



Product Description:

The **OxyPro Painter Aero** Kit provides respiratory protection for painting jobs. It combines A2 class filters with P3 dust filters, providing protection against both organic solvent vapors and particulates. Ideal for painting and spray painting applications.



Set contents:

- 1 × **Oxyline OxyPro X6** dual filter half mask (TPR rubber)
- 2 × **Oxyline OxyPro X705Lt A2** filter
- 4 × **Oxyline OxyPro X7N13 P3 D** dust prefilter
- 2 × **Oxyline OxyPro X501** prefilter cover

Application:

- Painting work
- Spray painting with protection against vapors and dust

Description of individual components of the set:

- **OxyPRO X6 Half Mask** - X6 half mask made of TPR rubber, reusable, with two bayonet connectors, protects against gases, vapors and dusts. Ergonomic shape provides a good field of vision and compatibility with eye protection. Available in sizes S, M, L. Complies with the EN 140 standard
- **OxyPro X705Lt A2 Filter** - The X705 A2 filter protects against organic vapors and gases (boiling point > 65°C, up to 0.1%), features a bayonet connection and a rear design that improves the field of view. Fits X6, X7, and X8 half masks. Complies with EN 14387.
- **OxyPRO X7N13P3D Dust Prefilter** - The X7N13 P3 D filter protects against non-toxic and medium-toxic aerosols (dust, smoke, mist), used with the X501 attachment and X701, X702, X703 filters. Fits X6, X7, and X8 masks. Recommended for up to 3 work shifts. Complies with the EN 143 standard.
- **OxyPRO X501 pre-filter cover** - The X501 cover allows the X7N11 P2 R D filter to be mounted on X701, X702, X703, X705 absorbers, extending protection to include solid particles. Compatible with X6, X7 half masks and X8 full face masks

Packing:

The sets are packed 20 pieces in a collective EXPORT box measuring 600 × 500 × 400 mm. Each set is labelled with a dedicated label. The weight of a full box is 11.1 kg.

REFERENCE CODE	SIZE
ZX6SLTA27N13P3-w	S
ZX6MLTA27N13P3-w	M
ZX6LLTA27N13P3-w	L