



## TECHNICAL SHEET FA 30 503 15

### ENERGY ABSORBING KERNMANTLE ROPE LANYARD



#### Energy Absorbing Kernmantle Rope Lanyard

- Energy absorber in 44 mm wide webbing which reduces the impact of the fall to less than 6 kN
- 12 mm diam polyamide Kernmantle rope lanyard
- Loops protected by an abrasion resistant thimble
- Sewing protected with strong transparent covering sleeve.

**Connectors :** 1 connector double action with automatic locking, opening 17 mm, reference FA5020217 and 1 scaffold hook double action with automatic locking, opening 55 mm, reference FA5020755

**Compliance :** EN355 : 2002 and tested as per VG11 - 89/686/EEC

#### Material of components:

Lanyard : polyamide  
Absorber : polyester et polyamide  
Connectors : steel

<b>Size:</b> 1.5 mtr (connectors included)	<b>CE</b>	<b>Weight:</b> 1.16 kg
--	-----------	---------------------------

**KRATOS SAFETY**  
689 Chemin du Buclay  
38540 Heyrieux – FRANCE

Tel : +33 (0)4 72 48 78 27  
Fax : +33 (0)4 72 48 58 32

[www.kratossafety.com](http://www.kratossafety.com) / [info@kratossafety.com](mailto:info@kratossafety.com)

<b>HS CODE</b> 56090090
<b>CARTON SIZE / PCS.</b> 60 x 40 x 24 / 10
<b>AET N°4334 I2 E5</b>
Satra Technology Centre, N°0321 Wyndham Way, Telford Way, Kettering Northamptonshire, NN16 8SD, United Kingdom
<b>ARTICLE 11 GB07/73551</b>
SGS United Kingdom Ltd., N°0120 Unit 202B, Worle Parkway, Weston-super-Mare, BS22 6WA, United Kingdom