



## TECHNICAL SHEET FA 30 512 12

### KERNMANTLE ROPE LANYARD WITH ENERGY ABSORBER, LGTH. 1.2 MTR

**gravity-s**



- Energy absorber in 35mm wide webbing which reduces the impact of the fall to less than 6 KN. Energy absorber equipped with a fall indicator:



- Black sleeve for a better UV resistance.
- 12 mm diam. polyamide Kernmantle rope lanyard, specially designed to withstand sharp edges.



- Loops protected by an abrasion-resistant thimble.
- Sewing protected with strong transparent covering sleeve.

#### Connectors:

1 aluminium scaffold hook, opening 60 mm (FA 50 218 60) and 1 aluminium screw-locking karabiner, opening 22.5mm (FA 50 105 22B).

**Compliance:** EN355:2002, and tested as per VG11 of PPE Directive 89/686/EEC.

#### Material of components:

Lanyard: Polyamide Kernmantle rope

Absorber: Polyester and Polyamide

Connectors: Aluminium

Length:	<b>CE</b>	Weight:
1.20 mtr		0.45 kg

#### KRATOS SAFETY

689 Chemin du Buclay  
38540 Heyrieux – FRANCE

Tel. : +33 (0)4 72 48 78 27

Fax : +33 (0)4 72 48 58 32

[www.kratossafety.com](http://www.kratossafety.com) / [info@kratossafety.com](mailto:info@kratossafety.com)

#### HS CODE

5609 00 90

#### CARTON SIZE / PIECES

80 x 40 x 24 cm / 10

#### AET N° 4334 I4 E6

Satra Technology Centre, N°0321  
Wyndham Way, Telford Way, Kettering  
Northamptonshire, NN16 8SD, United Kingdom

#### ARTICLE 11 GB07/73551

SGS United Kingdom Ltd., N°0120  
Unit 202B, Worle Parkway,  
Weston-super-Mare, BS22 6WA, United Kingdom