



TECHNICAL SHEET

FA 30 810 15

Designation :

Forked Expandable Lanyards

- Energy absorber in 35 mm wide webbing which reduces the impact of the fall to less than 6 kN
- 44 mm wide polyester expandable webbing lanyard
- Loops protected by an abrasion resistant tubular webbing.
- Seem protected by a transparent shelth.

Connectors :

2 aluminium connectors opening 60 mm, to closure and automatic lock and 1 aluminium connector opening 22 mm, ref. FA 50 105 22.

Compliance :

EN355 : 2002 and tested as per VG11 - 89/686/CEE



Length :

Expanded length: 1,5 m (Connectors included)
Relaxed length : 1 m (Connectors included)

Materials :

Lanyards : polyamide

Absorbers : polyester and polyamide

Connectors : aluminium

HS code

56090090

Carton size / pieces

40x40x24 /10

Unit weight

1.41 Kg

AET: N° 4345 Issue 5 Extension 4

Satra Technology Centre, N°0321
Wyndham Way, Telford Way, Kettering,
Northamptonshire, NN16 8SD, United Kingdom.

Article 11: GB07/73551

SGS United Kingdom Ltd., N° 0120
Unit 202B, Worle Parkway,
Weston-super-Mare, BS22 6WA, United Kingdom



Maj. : 10/14

**ZI les portes du Dauphiné
4 rue de l'Aigue**

69 780 St Pierre de Chandieu – France

Tel : +33 (0)4 72 48 78 27 Fax : + 33 (0)4 72 48 58 32

www.kratossafety.com info@kratossafety.com

