



TECHNICAL SHEET FA 20 200 02

Rope grab for KS 6000 System



KS 6000

	Weight:
	0.82 kg

KRATOS SAFETY

689 Chemin du Buclay
38540 Heyrieux – FRANCE

Tel : +33 (0)4 72 48 78 27

Fax : +33 (0)4 72 48 58 32

www.kratossafety.com / info@kratossafety.com

- Works on KS 6000 system in stainless steel wire rope, diameter 8 mm.
- Works on rigid system.
- Its design allows to install/uninstall the rope grab everywhere on the wire rope.
- Has a non-inverting system to prevent installing the device upside down on the system.
- Has a small energy absorber.
- Minimum breaking strength > 15 kN.

Connectors:

1 stainless steel quick link, and 1 steel screw-locking karabiner 18 mm, ref. FA 50 101 17 for connection on a harness.

Compliance: Complies with EN 353-1 : 2014.

Material of components:

Rope Grab: Stainless steel

Connector: Steel (screw-locking) / Stainless steel (quick link).

Energy absorber: Polyester

HS CODE

56090090

CARTON SIZE / PCS.

60 x 40 x 24 cm / 20

AET N°8756 I5 E1

Satra Technology Centre, N°0321
Wyndham Way, Telford Way, Kettering
Northamptonshire, NN16 8SD, United Kingdom

ARTICLE 11 GB07/73551

SGS United Kingdom Ltd., N°0120
Unit 202B, Worle Parkway,
Weston-super-Mare, BS22 6WA, United Kingdom