



TECHNICAL SHEET FA 10 204 01

HARNES 2 ATTACHMENT POINTS WITH COMFORTABLE WORK POSITIONING BELT AND 3 AUTOMATIC BUCKLES



140
kg



Covered
identification
label

Attachment points:

1 dorsal D-ring with extension band ● (A) for fall arrest, 1 sternal D-Ring ● (A/2) for fall arrest system with textile loops and 2 lateral D-Rings ● for work positioning.

Adaptability:

Adjustable shoulder, thigh straps and waist belt.

Convenience:

Shoulder and thigh straps differentiated by a dual color scheme. 4 tool-holding webbing loops and 3 tool-holding rings at the back for keeping extra karabiners and accessories. Extension band (length: 30 cm) which allows the user to easily connect himself to the dorsal attachment D-ring without any external help.

Ergonomics:

Soft padding on shoulder and waist straps for an extended comfort. Thigh straps and waist strap are provided with automatic buckles for easy adjustment. Ideally positioned sit strap for extended comfort.

Compliance: Conforms to EN 361 : 2002 and EN 358 : 2000.

Material of components:

Straps: Polyester

Buckles: Steel

Size :	CE	Weight :
Single size		2.22 kg

KRATOS SAFETY

689, chemin du Buclay
38540 Heyrieux – FRANCE

Tel : +33 (0)4 72 48 78 27

Fax : +33 (0)4 72 48 58 32

www.kratossafety.com / info@kratossafety.com

HS CODE
6307 20 90
CARTON SIZE / PIECES
60 x 40 x 24 cm / 5
AET N°2342 Issue 10 Extension 5
Satra Technology Centre, N°0321 Wyndham Way, Telford Way, Kettering Northamptonshire, NN16 8SD, United Kingdom
ARTICLE 11 GB07/73551
SGS United Kingdom Ltd., N°0120 Unit 202B, Worle Parkway, Weston-super-Mare, BS22 6WA, United Kingdom