





Body harness with rotative belt (S - L)



140
kg

Attachment points:

1 dorsal D-Ring (A) , 1 chest attachment made of 2 textile loops (A/2) , an extension strap  attached on the dorsal D-Ring for fall arrest, 2 lateral D-Rings  for work positioning.

Adaptability:

Adjustable chest strap, shoulders, thigh straps and waist belt.


Convenience:

Shoulder straps are elasticated and have combination buckles.



Chest strap, thigh straps, waist strap are provided with automatic buckles for easy adjustment.


4 tool-holding loops and 1 extra bigger handle at waist level for keeping extra karabiners and accessories.

2 bended D-rings on the belt.

With protected identification label. 

Ergonomics:

Special rotative belt (180°)   and elastic straps for easy mobility and great comfort.



Compliance: EN361:2002 and EN358:2000.

Material of components:

Straps: Polyester

Buckles: Steel

Size:		Weight:
S - L		2.25 kg

KRATOS SAFETY

689 Chemin du Buclay
38540 Heyrieux – FRANCE

Tel : +33 (0)4 72 48 78 27

Fax : +33 (0)4 72 48 58 32

www.kratossafety.com / info@kratossafety.com

HS CODE

6307 20 90

CARTON SIZE / PIECES

60 x 40 x 24 / 5

AET N°5596 Issue 2

Satra Technology Centre, N°0321
Wyndham Way, Telford Way, Kettering
Northamptonshire, NN16 8SD, United Kingdom

ARTICLE 11 GB07/73551

SGS United Kingdom Ltd., N°0120
Unit 202B, Worle Parkway,
Weston-super-Mare, BS22 6WA, United Kingdom