



## TECHNICAL SHEET FA 20 501 06

### Olympe-S webbing, retractable fall arrester 6 m



- Casing made up of high impact strength Polymer, to prevent breakage.
- Comes with a 25 mm wide Polyester webbing.
- Internal braking mechanism to reduce the fall arrest force to less than 6 kN.
- Comes with an external inbuilt energy absorber.
- Swivel at anchorage end and attachment end.

**Minimum breaking strength > 12 kN.**

**Connectors:** Steel screw-locking karabiner FA 50 101 17, opening 18 mm, at anchorage end, and steel snap-hook FA 50 203 20, opening 20 mm, with load indicator at attachment end.

**Compliance:** EN360:2002.

Tested and approved for horizontal use (work near sharp edges) according to VG 11.060 (Rev. 08 - 10/2014).

#### Material of components:

Protective casing: PA 6 30% fiberglass

Webbing: Polyester

Connectors: Steel

Length :	<b>CE</b>	Weight :
6 m		2.71 kg

#### KRATOS SAFETY

ZI les Portes du Dauphiné  
4, rue de l'Aigue  
69780 Saint Pierre de Chandieu – FRANCE

Tel : +33 (0)4 72 48 78 27

Fax : +33 (0)4 72 48 58 32

[www.kratossafety.com](http://www.kratossafety.com) / [info@kratossafety.com](mailto:info@kratossafety.com)

#### HS CODE

8428 90 90

#### CARTON SIZE / PIECES

80 x 40 x 24 cm / 4

#### AET N°8087 Issue 3 Extension 1

Satra Technology Centre, N°0321  
Wyndham Way, Telford Way, Kettering  
Northamptonshire, NN16 8SD, United Kingdom

#### ARTICLE 11 GB07/73551

SGS United Kingdom Ltd., N°0120  
Unit 202B, Worle Parkway,  
Weston-super-Mare, BS22 6WA, United Kingdom