



# FILTER

**Model: 203 AXP3 NR D**  
**P/N 124550000**

Combined filter with standard thread connector to **EN 148-1** for organic vapours having boiling point lower than 65 °C, dusts, fumes, mists.

The filter can be used with full face masks type **TR 82**, **TR 2002 CL2** and **TR 2002 CL3** or equivalent, provided that they are fitted with EN 148-1 connector.



## TECHNICAL DATA

### Breathing resistance

at 30 l/min: 1.4 mbar

at 95 l/min: 5.6 mbar

### Duration at gases

Filter type	Class	Test Gas	Test Concentration (PPM)	Test Flow (l/min)	Testing HR (%)	Breakthrough concentration (PPM)	Duration Required (min)	Duration Tested (min)
AX	/	CH <sub>3</sub> OCH <sub>3</sub>	500	30	70	5	50	85
		C <sub>4</sub> H <sub>10</sub>	2500	30	70	5	50	64

### Performance particle filtration

Filter type	Penetration (l/min)	Test Aerosol	Penetration Max Allowed (%)	Test 1 (%)	Test 2 (%)	Test 3 (%)
P R	95	NaCl	0.05	0.0019	0.0019	0.0008
		Paraffin oil	0.05	0.0007	0.0008	0.0009

Test Filter Type :

Test 1: Penetration (media calculated 30 sec after the test beginning)

Test 2: Max Penetration till 120 mg aerosol exposition

Test 3: Penetration (media calculated 30 sec after the test beginning) after 120 mg aerosol exposition and 24h storage



# FILTER

Model: 203 AXP3 NR D

P/N 124550000

## "D" clogging test with Dolomite Dust.

Filter is submitted to a clogging test with a concentration of Dolomite of 263 mg.h.m<sup>3</sup>.  
Inhalation resistance: a 95 l/min: 8.4 mbar (request < 10.5 bar)

Filter type	Test Flow	Test Aerosol	Penetration Max Allowed (%)	Penetration Max Measured (%)
P R	95	NaCl	0.05	0.0008
		Paraffin oil	0.05	0.0008

Marking D means the filter passed the clogging test with Dolomite dust and it has high performance in dusty and sandy settings.

## Limitations for use

Do not use in areas where the oxygen concentration is lower than 17% in volume nor in presence of gases different from those clearly indicated.

## CLASSIFICATION

Filter complying with the provisions of Regulation (EU) **2016/425**.

**Combined Filter, class 2** for gas protection and particle filter **class P3 NR**, to **EN 14387:2004 + A1:2008**.

Label colour code: brown, white.

## MARKING



## MATERIALS

Housing: polypropylene

Filter Media: activated carbon and filter paper

## STORAGE

Store at temperatures between -20 and +50 °C and RH <80%

## WEIGHT

310 g approximately

## DIMENSIONS/PACKING

The filter is sold in 4 piece boxes with dimensions 220 x 220 x 110 mm

## SHELF LIFE

Filters duly stored and in their original packaging will last five years from production. The expiry date is stamped onto the filter label and its packaging.

For more information please check the notes along with the products or the ones published on the website: [www.spasciani.com](http://www.spasciani.com)

*NOTE: SPASCIANI SpA does not take any responsibility for any possible and unintentional mistake and reserve the faculty of modify materials and technical characteristics of its products at any time and without any notice. The pictures are purely indicative and may not represent the actual product described in the text.*