

# FILTER

**Model: 202 AX****P/N 124430000**

Gas filter with standard thread connector to **EN 148-1** for organic vapours having boiling point lower than 65°C. The filter can be used with full face masks type **TR 82**, **TR 2002 CL2** and **TR 2002 CL3** and half mask **ST 85** or equivalent, provided that they are fitted with EN 148-1 connector.



## TECHNICAL DATA

### Breathing resistance

at 30 l/min: 0.9 mbar

at 95 l/min: 3.7 mbar

### Duration at gases

Filter type	Class	Testing Gas	Testing Concentration (PPM)	Testing Flow (l/min)	Testing HR (%)	Breakthrough concentration (PPM)	Duration Required (min)	Duration Tested (min)
AX	/	CH <sub>3</sub> OCH <sub>3</sub>	500	30	70	5	50	85
		C <sub>4</sub> H <sub>10</sub>	2500	30	70	5	50	64

### Limitations for use

Do not use in areas where the oxygen concentration is lower than 17% in volume nor in presence of gases different from those clearly indicated, dusts, fumes and mists.

**WARNING:** This filter shall be used only once.

### CLASSIFICATION

Filter complying with the provisions of Regulation (EU) **2016/425**.

**Gas Filter Type AX**, to **EN 14387:2004 + A1:2008**.

Label colour code: brown.

### MARKING

**CE**



## **FILTER**

**Model: 202 AX**  
**P/N 124430000**

### **MATERIALS**

Housing: polypropylene  
Filter Media: activated carbon

### **STORAGE**

Store at temperatures between -20 and +50 °C and RH <80%

### **WEIGHT**

275 g approximately

### **DIMENSIONS/PACKING**

The filter is sold in 4 piece boxes with dimensions 220 x 220 x 110 mm

### **SHELF LIFE**

Filters duly stored and in their original packaging will last five years from production. The expiry date is stamped onto the filter label and its packaging.

---

**For more information please check the notes along with the products or the ones published on the website: [www.spasciani.com](http://www.spasciani.com)**

*NOTE: SPASCIANI SpA does not take any responsibility for any possible and unintentional mistake and reserve the faculty of modify materials and technical characteristics of its products at any time and without any notice. The pictures are purely indicative and may not represent the actual product described in the text.*