



TECHNICAL SHEET FA 30 514 20

ENERGY ABSORBING KERNMANTLE ROPE LANYARD WITH RING ADJUSTER

gravity



Energy absorbing kernmantle rope lanyard with ring adjuster

- Energy absorber in 35 mm wide webbing which reduces the impact of the fall to less than 6 KN.
- Black protective sleeve for increased longevity and UV resistance.
- Has a fall indicator label.
- 12mm diam. Polyamide kernmantle rope lanyard, with ring adjuster.
- Loops protected by an abrasion resistant thimble.
- Spliced end protected with strong covering sleeve.

Connectors: 1 aluminum scaffold hook opening 60 mm, ref. FA 50 218 60 and 1 aluminum screw-locking karabiner opening 22 mm, ref. FA 50 105 22B.

Compliance: EN 355:2002.

Material of components:

Lanyards: polyamide
 Absorber: polyester and polyamide
 Connectors: aluminum
 Ring adjuster: Steel

Size:		Weight:
Maximum 2 mtr (connectors included)		1.01 kg

KRATOS SAFETY

689 Chemin du Buclay
 38540 Heyrieux – FRANCE

Tel : +33 (0)4 72 48 78 27
 Fax : +33 (0)4 72 48 58 32

www.kratossafety.com / info@kratossafety.com

HS CODE
56090090
CARTON SIZE / PCS.
80 x 40 x 24 x 10
AET N°4334 I5 E1
Satra Technology Centre, N°0321 Wyndham Way, Telford Way, Kettering Northamptonshire, NN16 8SD, United Kingdom
ARTICLE 11 GB07/73551
SGS United Kingdom Ltd., N°0120 Unit 202B, Worle Parkway, Weston-super-Mare, BS22 6WA, United Kingdom