



TECHNICAL SHEET FA 30 600 10

Kernmantle rope lanyard with energy absorber, lg. 1 m



Forked Kernmantle rope lanyard made up of:

- Energy absorber in 45 mm wide webbing, which reduces the impact of the fall to less than 6 kN,
- Energy absorber protected by a black shrink sleeve for a better UV resistance,
- Has a fall indicator label,
- 11 mm diam. Polyamide Kernmantle rope lanyard,
- Loops protected by an abrasion resistant thimble,
- Stitches protected with strong transparent covering sleeve.

Connectors:

2 steel scaffold hooks opening 55 mm, ref. FA 50 207 55 and 1 steel screw-locking karabiner opening 17 mm, ref. FA 50 101 17.

Compliance: EN355 : 2002 and tested as per VG11 - 89/686/CEE

Material of components:

Lanyards: polyamide

Energy absorber: polyester and polyamide

Connectors: steel

Length :	CE	Weight:
1 m		1.60 kg

KRATOS SAFETY

689 Chemin du Buclay
38540 Heyrieux – FRANCE

Tel : +33 (0)4 72 48 78 27
Fax : +33 (0)4 72 48 58 32

www.kratossafety.com / info@kratossafety.com

HS CODE
56090090
CARTON SIZE / PCS.
60 x 40 x 24 cm / 10
AET N°4333 I7 E3
Satra Technology Centre, N°0321 Wyndham Way, Telford Way, Kettering Northamptonshire, NN16 8SD, United Kingdom
ARTICLE 11 GB07/73551
SGS United Kingdom Ltd., N°0120 Unit 202B, Worle Parkway, Weston-super-Mare, BS22 6WA, United Kingdom