



Lightweight, robust and easy-to-use grip descender.

The ergonomic handle allows controlling the descent.

High flow when one needs to regain slack (rope climbing).

Provided with a safe locking eye, which prevents the rope from sliding out when operating as a descender.

Works on 10-11 mm diam. Kernmantle rope.

Recommended for rope access, double rope descent, rescue and evacuation.

Compliance: EN341:2011/2B, EN 12841:2006 Type C.

Material of components:

Aluminium, black anodized finish.

CE	Weight:
	0.450 kg

KRATOS SAFETY

689 Chemin du Buclay
38540 Heyrieux – FRANCE

Tel : +33 (0)4 72 48 78 27

Fax : +33 (0)4 72 48 58 32

www.kratossafety.com / info@kratossafety.com

HS CODE

84289090

CARTON SIZE / PCS.

40 X 30 X 20 cm / 40

Satra Technology Centre, N°0321
Wyndham Way, Telford Way, Kettering
Northamptonshire, NN16 8SD, United Kingdom

ARTICLE 11 GB07/73551

SGS United Kingdom Ltd., N°0120
Unit 202B, Worle Parkway,
Weston-super-Mare, BS22 6WA, United Kingdom