




Length :	CE	Weight :
40 m		4.93 kg

KRATOS SAFETY

 689 Chemin du Buclay
 38540 Heyrieux – FRANCE

Tel : +33 (0)4 72 48 78 27

Fax : +33 (0)4 72 48 58 32

www.kratossafety.com / info@kratossafety.com

Res-Q is the perfect device for quick rescue operations. Made of aluminium alloy and high-strength steel and 9.6 mm diameter semi static kernmantle rope assembled with the device.

Rope ends with double figure of 8 knots for connection with karabiner. Provided with 3 hooks ref. FA 50 220 21.

- **Controlled descent speed:** 0.8 m / sec, regardless the weight (max. weight 150 kg).
- **Maximum descent height:** 300 m.
- **Brake system:** Automatic.
- **Maximum no. of users:** 1 user < 150 kg.
- **Inspection:** Once a year or every 2000 m of rope.

Available in 2 lengths: 20 m (FA 70 101 20), 40 m (FA 70 101 40).

Compliance: EN 341:2011-1B.

Material of components:

Rope: polyamide diam. 9,6 mm (EN 1891-A)

Device: aluminium alloy and high-strength steel

HS CODE
CARTON SIZE / PIECES
AET N°2015-4469 / EMZ
AUVA-STP N° 0511

 Adalbert-Stifter Straße 65
 1200 Vienna, Austria

Module C2, 2016/425 UE Regulation
AUVA-STP N° 0511

 Adalbert-Stifter Straße 65
 1200 Vienna, Austria