



	<b>Weight:</b>
	4.75 kg

**KRATOS SAFETY**

689 Chemin du Buclay  
38540 Heyrieux – FRANCE

Tel : +33 (0)4 72 48 78 27

Fax : +33 (0)4 72 48 58 32

[www.kratossafety.com](http://www.kratossafety.com) / [info@kratossafety.com](mailto:info@kratossafety.com)

## Door Anchor

- Transportable anchorage point designed to be used for doorways and windows.
- Simple and robust design.
- Its non-penetrating installation does not damage the host structure
- No specific tools are required for its installation.
- Can be installed on frames with dimensions from 60 to 125 cm, and can be used by 2 people at the same time.
- Minimum breaking strength : > 13kN
- **Can be used according to the 2 following setups:**

- **On window frame (facade), use in « vertical » setup:** combined with a fall arrest EN360, EN355 or EN353 in order to catch the user in case of a fall.

- **On doorframe (indoors), use in « horizontal » setup:** combined with a work restraint system EN358 in order to prevent the user from accessing to an area where there is a risk of falling.

- **Compliance :** Complies with EN 795 : 2012 Type B

**Material of components:**

Aluminium

**HS CODE**

83081010

**CARTON SIZE / PCS.**

157 x 24 x 10 / 1

**AET N°6176 I1 E1**

Satra Technology Centre, N°0321  
Wyndham Way, Telford Way, Kettering  
Northamptonshire, NN16 8SD, United Kingdom

**ARTICLE 11 GB07/73551**

SGS United Kingdom Ltd., N°0120  
Unit 202B, Worle Parkway,  
Weston-super-Mare, BS22 6WA, United Kingdom