



TECHNICAL SHEET FA 10 215 00

HYBRID AIRTECH, COMFORTABLE MULTIPURPOSE BODY HARNESS (S-L)

Hybrid AIRTECH

140
kg



Universal body harness, ideal for industrial works, and for suspension work as well. It is specifically designed to facilitate the vertical movements on rail or cable system. Quick and easy to put on, ultra-comfortable and multipurpose.

Attachment points - 1 dorsal D-ring (A) ● and 1 sternal attachment (A/2) ● made of 2 textile loops for fall arrest system, 1 ventral attachment ● made of 2 textile loops at waist level for rope access, and 2 lateral D- Rings ● for work positioning.

Adaptability - Adjustable shoulder, belt and lower part of the thigh straps. Totally openable, can be put on with the feet on the ground.

Convenience - Thigh straps and belt strap are provided with automatic buckles for easy adjustment. 4 equipment-holding handles for keeping extra karabiners and accessories, and 2 tool-holding D-rings.

Ergonomics - Soft padding on waist and leg straps for extended comfort. Pull-down D-rings, to avoid unintentional bumping.

Compliance: Conforms with EN 361:2002, EN 358:1999 and EN 813:2008.

Material of components:

Straps: Polyester

D-rings: Aluminium

Buckles: Steel and Aluminium

Size :	CE	Weight:
S-L Exists in L-XXL (ref. FA 10 215 01)		2.17 kg

KRATOS SAFETY

689, chemin du Buclay
38540 Heyrieux – FRANCE

Tel : +33 (0)4 72 48 78 27

Fax : +33 (0)4 72 48 58 32

www.kratossafety.com / info@kratossafety.com

HS CODE

6307 20 90

CARTON SIZE / PIECES

60 x 40 x 24 cm / 5

AET (UE) N°2777-10872-01-E00-00

Satra Technology Europe Ltd., N° 2777,

Bracetown Business Park, Clonee,
Dublin, D15YN2P, Ireland

MODULE D GB07/73551

SGS United Kingdom Ltd., N°0120,

Unit 202B, Worle Parkway,
Weston-super-Mare, BS22 6WA, United Kingdom