



TECHNICAL SHEET FA 40 600 10

RESTRAINT FORKED LANYARD 1 M



Restraint Forked Kernmantle Rope Lanyard

- Made up of 12mm diam. polyamide kernmantle rope.
- Abrasion resistant thimble to protect the loops from being damaged by metallic contact.
- Sewing protected with a strong transparent covering sleeve which protects the ends and also make stitches visible for easy inspection before the use.
- **Breaking strength : 22 kN**

Connectors: 1 steel snap hook FA 50 202 17, opening 17 mm, and 2 steel scaffold hooks FA 50 207 55, opening 50,8 mm.

Compliance : EN 354:2010.

Material of components:

Lanyard: Polyamide

Connectors: Steel

Length :	CE	Weight :
1 m		1.45 kg

KRATOS SAFETY

689 Chemin du Buclay
38540 Heyrieux – FRANCE

Tel.: +33 (0)4 72 48 78 27

Fax.: +33 (0)4 72 48 58 32

www.kratossafety.com / info@kratossafety.com

HS CODE

5607 50 90

SIZE CARTON / PIECES

60 x 40 x 24 cm / 10

AET N° 2577 I8 E6

Satra Technology Centre, N°0321

Wyndham Way, Telford Way, Kettering
Northamptonshire, NN16 8SD, United Kingdom

ARTICLE 11 GB07/73551

SGS United Kingdom Ltd., N°0120

Unit 202B, Worle Parkway,
Weston-super-Mare, BS22 6WA, United Kingdom