



TECHNICAL SHEET FA 40 903 40

Work positioning kernmantle lanyard with grip adjuster, max 4 m



- Made up of 12mm diam. polyamide kernmantle rope.
- Abrasion resistant thimble to protect the loops from being damaged by contact with metal parts.
- **Mobile textile protective sleeve** (length 1.50 m) against abrasion and cuts.
- Stitches protected under a strong protective sleeve, which allows a visual checking.
- Grip adjuster for a progressive movement.

Connectors:

1 steel screw-locking karabiner opening 17 mm, ref. FA 50 101 17, and 1 snap hook ref. FA 50 202 17.

Compliance: EN358:1999.

Material of components:

Lanyard: polyamide
 Protective sleeve: polyester
 Connectors and grip adjuster: steel

Length:	CE	Weight:
Max. 4 m		1.30 kg

KRATOS SAFETY

689 Chemin du Buclay
 38540 Heyrieux – FRANCE

Tel : +33 (0)4 72 48 78 27
 Fax : +33 (0)4 72 48 58 32

www.kratossafety.com / info@kratossafety.com

HS CODE

56075090

CARTON SIZE / PCS.

80 x 40 x 24 cm / 20

AET N° 3884 I2 E4

Satra Technology Centre, N°0321
 Wyndham Way, Telford Way, Kettering
 Northamptonshire, NN16 8SD, United Kingdom

ARTICLE 11 GB07/73551

SGS United Kingdom Ltd., N°0120
 Unit 202B, Worle Parkway,
 Weston-super-Mare, BS22 6WA, United Kingdom