



TECHNICAL SHEET FA 20 100 00B

FALL ARRESTER ON POLYAMIDE TWISTED ROPE WITH ENERGY ABSORBING LANYARD



Fall arrester on polyamide twisted rope with energy absorbing lanyards

- Works on the anchor line *KRATOS SAFETY* in polyamide twisted rope, diameter 14-16 mm.
- Supplied with an energy absorber FA 30 000 45
- Simple opening / closing and automatic locking by a double security system.
- Has a manual locking position to allow work on inclined roof. **(A)**
- Has a unique non-inverting system to prevent from installing the device upside down on the anchor line. **(B)**
- Minimum breaking strength > 15 kN

Connectors :

1 steel screw-locking karabiner opening 17 mm, ref. FA 50 101 17 for connection on a harness.

Compliance : Conforms to EN 353-2 : 2002

Material of components:

Rope Grab : Steel

Connector : Steel

Absorber : Polyester and polyamide

	Weight:
	1.20 kg

KRATOS SAFETY

689 Chemin du Buclay
38540 Heyrieux – FRANCE

Tel : +33 (0)4 72 48 78 27

Fax : +33 (0)4 72 48 58 32

www.kratossafety.com / info@kratossafety.com

HS CODE

83081010

CARTON SIZE / PCS.

60 x 40 x 24 / 20

AET N°2664 I3 E3

Satra Technology Centre, N°0321
Wyndham Way, Telford Way, Kettering
Northamptonshire, NN16 8SD, United Kingdom

ARTICLE 11 GB07/73551

SGS United Kingdom Ltd., N°0120
Unit 202B, Worle Parkway,
Weston-super-Mare, BS22 6WA, United Kingdom