

TURBINE CFU

PAPR respirator with helmet

TURBINE CFU is a Powered Air Purifying Respirator (PAPR) for breathing protection with **ABS lightweight safety helmet** to EN 397 incorporating a **flip-up polycarbonate visor** offering impact protection to EN 166 1 B. The visor is fitted with a replaceable Proban flame retardant face seal.

Besides the helmet, **TURBINE CFU** comes with **electric fan TURBINE 170** complete with waist belt and soft pad, **corrugated hose TUR 802**.

The filters have to be used in pairs and can be chosen between particle and combined filters according to the field of use.

The charger is not a component of the Respiratory Protection Device. It has to be ordered separately.



CLASSIFICATION

Powered filtering devices with helmet certified to **EN 12941 class TH2P**.

Safety helmet to **EN 397 - MM, -20 °C/-30 °C, -40 °C, LD, 440Va.c./1000Va.c** for head protection.

Flip-up visor to **EN 166 1 B 9 3** for impact protection.

Complying with the provisions of Regulation (EU) **2016/425**.

MARKING



WEIGHT

2,2 Kg approximately with particle filters

2,6 Kg approximately with combined filters