



TECHNICAL SHEET FA 10 214 01

REVOLTA Full Body Harness 2 attachment points (L - XXL)




REVOLTA

SERIES



Sit-harness, ideal for use in a variety of applications including petrochemical, painting, water treatment, food processing, offshores, general industry...

Attachment points:

1 dorsal D-Ring , 2 chest attachment textile loops (A/2)  for fall arrest system and 2 lateral bended D-Rings  for work positioning.

Adaptability:

Adjustable shoulder, thigh straps and waist belt. Shoulder straps have combination buckles.

Convenience:

Chest strap, thigh straps and waist strap are provided with automatic buckles for easy adjustment.

Oil, water and dirt-repellent REVOLTA webbing, which makes it tear and cut-resistant for increased durability and longevity. Highly UV-resistant.



4 tool-holding loops and 1 extra bigger handle at waist and thigh level for keeping extra karabiners and accessories. Identification and verification tracking labels protected by an openable cover. The name of the user can be written on the cover.

Ergonomics:

Soft padding on thigh straps for an extended comfort.


Compliance: EN361:2002 and EN358:2000.

Material of components:

Straps: Polyester with water, oil & dirt-repellent coating

Attachment D-rings: Aluminium

Other buckles: Steel

Size :		Weight :
L – XXL (also available in S-L : FA 10 214 00)		2.30 kg

KRATOS SAFETY

689 Chemin du Buclay
38540 Heyrieux – FRANCE

Tel.: +33 (0)4 72 48 78 27

Fax: +33 (0)4 72 48 58 32

www.kratossafety.com / info@kratossafety.com

HS CODE
6307 20 90
CARTON SIZE / PIECES
60 x 40 x 24 / 5
AET N°5596 Issue 2
Satra Technology Centre, N°0321 Wyndham Way, Telford Way, Kettering Northamptonshire, NN16 8SD, United Kingdom
ARTICLE 11 GB07/73551
SGS United Kingdom Ltd., N°0120 Unit 202B, Worle Parkway, Weston-super-Mare, BS22 6WA, United Kingdom