



## TECHNICAL SHEET FA 30 500 15

### ENERGY ABSORBING KERNMANTLE ROPE LANYARD



#### Energy Absorbing Kernmantle Rope Lanyard

- Energy absorber in 44 mm wide webbing, which reduces the impact of the fall to less than 6 kN,
- 12 mm diam. polyamide Kernmantle rope lanyard,
- Loops protected by an abrasion resistant thimble,
- Sewing protected with strong transparent covering sleeve.

**Compliance:** EN355 : 2002 and tested as per VG11 - 89/686/EEC.

#### Material of components:

Lanyard: Polyamide.

Energy absorber: Polyester and Polyamide.

Size:	<b>CE</b>	Weight:
1.5 mtr		0.39 kg

#### **KRATOS SAFETY**

689 Chemin du Buclay  
38540 Heyrieux – FRANCE

Tel : +33 (0)4 72 48 78 27

Fax : +33 (0)4 72 48 58 32

[www.kratossafety.com](http://www.kratossafety.com) / [info@kratossafety.com](mailto:info@kratossafety.com)

#### HS CODE

56090090

#### CARTON SIZE / PCS.

80 x 40 x 24 / 20

#### AET N°4334 I2 E2

Satra Technology Centre, N°0321  
Wyndham Way, Telford Way, Kettering  
Northamptonshire, NN16 8SD, United Kingdom

#### ARTICLE 11 GB07/73551

SGS United Kingdom Ltd., N°0120  
Unit 202B, Worle Parkway,  
Weston-super-Mare, BS22 6WA, United Kingdom