



PARTICLE & GAS REUSABLE MASK

...easy connection multiple protection



Filter absorber 703 A1B1E1K1

ref:
PG-703ABEK1

703 A1B1E1K1 is reusable and replaceable filter absorber with extended duration for half mask and two-way masks.

703 A1B1E1K1 absorber with special bayonet connection, protects against inorganic vapours at temperature above 65°C, sulphur dioxide (SO₂), ammonia (NH₃) and its derivatives. The housing construction is tiltable backwards which provides better vision.

703 A1B1E1K1 absorber has a bayonet connection for use with half masks and two-way masks 7500 and S600 series.

Use Limitations:

Do not use in environment in which the oxygen content is lower than 19.5% by volume and in the presence of unknown gases.

Packing:

1 pair in hermetic foil bag.
30 pairs in 1 carton box with dimensions of 530x245x235mm.
Weight of a carton box: 6,06 kg

Storage:

Store in original packing without air-purifying components, with instructions. At temperatures from -20°C to +30°C . Humidity RH<80%, Away from sunlight.

Shelf life:

Filters properly stored and originally packaged have an expiry date of 5 years from production dates. The production date is on the filter and on the packaging.

Certification:

In compliance with EN 14387:2004+A1:2008

AS/NZS 1716:2012

CE 2056

Notifying body: 2056
SAI Global Assurance Services Ltd.
Partis house, Ground Floor, Davy Avenue, Knowhill
Milton Keynes, MK5 8 HJ, United Kingdom



Housing: polypropylene
Absorber: Active carbon
Weight 1 piece: 101g

