



PARTICLE & GAS REUSABLE MASK

...easy connection multiple protection



7N11 P2 R Filter

ref:
PG-7N11

Particulate filter P2 R, reusable for half masks and two-way masks. Can be a pre-filter combined with cover model 501 on the absorbers model 701 and 702. Can be used for more than one working shift. It is recommended to use for no more than three shifts.

Filter 7N11 when applied with a suitable twin filter facepiece (half mask, mask) protects respiratory system against non-toxic and medium-toxic solid aerosols or water-based aerosols (dust, smoke, fog).

The 7N11 filters do not have a bayonet connector, so it should be used with a model 501 cover in combination with the absorber model 701 and 702. It can then be used with half masks and two-way masks FFS680, 7500 and S600.

Use Limitations:

Do not use in environment in which the oxygen content is lower than 19.5% by volume or in and in the presence of unknown gases.

Packing:

10 pieces in foil .
500 pcs carton box with
dimensions of 525x240x260mm
Weight of a carton box 1,5kg

Materials:

Filter: Non-woven filter fabric

Weight 1pc.: 3g

Storage:

Store in original packing without air-purifying components, with instructions. At temperatures from -20°C to +50°C . Humidity RH<80%, away from sunlight.

Lifespan:

Filters properly stored and originally packaged have an expiry date of 5 years from production dates. The production date is on the filter and on the packaging.

Certification:

In compliance with EN 143:2000+A1:2008

AS/NZS 1716:2012

CE 2056

Notifying body: 2056

SAI Global Assurance Services Ltd.

Partis house, Ground Floor, Davy Avenue, Knowhill
Milton Keynes, MK5 8 HJ, United Kingdom

