



PARTICLE & GAS REUSABLE MASK

...easy connection multiple protection



7500 SERIES

Half-masks with a bayonet fitting, reusable made from silicone

ref:

PG7500-M, PG7500-L

Half facepiece gas mask made from silicone 7500 series for use with two air-purifying components. The 7500 reusable half mask has two bayonet connections. Provides respiratory protection, protecting against a wide range of gases, vapors and dust. Its fitted ergonomic shape ensures optimal vision and is compatible with eye protection equipment. It is characterized by large resistance and durability. Evenly distributed weight on the user's face ensures comfort and tight fit, thanks to which the half-mask perfectly retains its position during various activities. The half mask allows easy access and quick inspection of the breathing membrane by removing the cover of the exhalation component. Half masks series 7500 are available in sizes M and L.



The 7500 respirator can be used with filters, absorbers and filter absorbers: 701 A1, 702 A1E1, 703A1B1E1K1, 702 A1E1P3R, 703 A1B1E1K1P3R, 793 P3, 793C P3 and with 2000.

Use Limitations:

Do not use in environment in which the oxygen content is lower than 19.5% by volume or in the presence of unknown gases.

Packing:

The mask is packed individually in a polyethylene bag.

20 pieces in one cardboard box with dimensions of 500x455x165mm.

Weight 1pc: 150g

Weight of a cardboard box 3kg

Storage:

Store in original packing without air-purifying components, with instructions.

At temperatures from -20°C to +50°C .

Humidity RH<80%, Away from sunlight.

Certification:

According to EN140:1998

PPE Directive 89/686/EAC

CE 2056

Notifying body: 2056

SAI Global Assurance Services Ltd.

Partis house, Ground Floor, Davy Avenue, Knowhill
Milton Keynes, MK5 8 HJ, United Kingdom

